


EN **MANUAL**




Attention! Insert correctly (+/-). Do not charge, do not disassemble, do not dispose of in fire, do not short circuit. Keep away from children. Do not use following batteries at the same time: old and new, half full and full, different brands and capacities. Remove immediately from device if not in use or the batteries are empty. Dispose of defective and empty batteries properly (hazardous waste).

Does not comply with the German StVZO - Not authorised for public road traffic! Please inform yourself about the regulations in your country.

Keep for future reference!

DE **BEDIENUNGSANLEITUNG**



Achtung! Polaritäten (+/-) beachten! Batterien nicht aufladen, nicht öffnen, nicht ins Feuer werfen oder kurzschließen. Von Kindern fernhalten. Folgende Batterien nicht gleichzeitig verwenden: alte und neue, halbvolle und volle, verschiedene Marken und Kapazitäten. Unverzüglich aus dem Gerät nehmen, wenn ungenutzt oder leer. Defekte und leere Batterien ordnungsgemäß entsorgen (Sondermüll).

Entspricht nicht der deutschen StVZO - Nicht für den öffentliche Straßenverkehr zugelassen! Informieren Sie sich über die Vorschriften Ihres Landes.

Anleitung sorgfältig aufbewahren!

distributed by:

***messingschlager***

Messingschlager GmbH & Co. KG  
Hassbergstr. 45  
96148 Baunach - Germany  
info@messingschlager.com  
www.messingschlager.com

**CE**

04/2025

