



Read this manual carefully before using and keep for future







INDICATOR CHARGING





- 1. Power off
- 2. Plug USB cable to USB port
- 3. Unplug after fully charged * Do not charge over 5V.

- **INDICATOR** batterv
- * Keep away from flammable objects while charaina.

Fully recharge the light at least every 3 months during storage.

Do not shine light directly into eyes. Do not mount near wireless computer,

Do not submerge the light into water. Keep light in cool and dry place when storing.

WARRANTY MOON lights are covered by a ONE YEAR LIMITED WARRANTY while MOON batteries are covered by 120 days warranty from

ANSI FL1

LUMEN

downward.

the date of purchase. This warranty covers the defects in material and workmanship only with proof of purchase. Please contact original dealer for warranty service. For lights bought on

MOON website, please contact cs@moon-sport.com for help. ONLINE WARRANTY REGISTRATION Visit www.moon-sport.com for online warranty registration.

WA-MOON-ORION-1809

Do not blind the oncoming vehicles. Always adjust the angle

To preserve battery when power is low, the light will enter safe mode with less light output for extra 2 hours. Safe mode cannot be override. Recharge battery for maximum performance.

AUTO SAFE MODE